



NOTE S1: BAND SW | EXT; 2.3.5MHz; 3.7MHz; 4.14MHz; 5.21MHz; 6.28MHz;
 7.28.5MHz; 8.29.1MHz; 9.50.0MHz; 10.50.5MHz; 11.JJY
 S2 FUNCTION 1.LSB.CW; 2.USB.CW; 3.STANDBY; 4.AM; 5.AM ANL

